- (g) Instructions for using the compatibility table for Class 1 (explosive) materials in paragraph (f) of this section are as follows:
- (1) A blank space in the Table indicates that no restrictions apply.
- (2) The letter "X" in the Table indicates that explosives of different compatibility groups may not be carried on the same rail car, unless packed in separate freight containers (e.g., two or more freight containers mounted upon the same rail car).
- (3) The numbers in the Table mean the following:
- (i) "1" means explosives from compatibility group L may only be carried on the same rail car with an identical explosive.
- (ii) "2" means any combination of explosives from compatibility group C, D, or E is assigned to compatibility group E.
- (iii) "3" means any combination of explosives from compatibility group C, D, or E with those in compatibility group N is assigned to compatibility group D.
- (iv) "4" means detonators and detonating primers, Division 1.4S (Class C explosives), may not be loaded in the same car with Division 1.1 and 1.2 (Class A explosive) materials.
- (v) "5" means Division 1.4S fireworks may not be loaded in the same car with Division 1.1 or 1.2 (Class A explosive) materials.
- (h) Except as provided in paragraph (i) of this section, explosives of the same compatibility group but of different divisions may be transported together provided that the whole shipment is transported as though its entire contents were of the lower numerical division (i.e., Division 1.1 being lower than Division 1.2). For example, a mixed shipment of Division 1.2 (Class A explosive) materials and Division 1.4 (Class C explosive) materials, compatibility group D, must be transported as Division 1.2 (Class A explosive) materials.
- (i) When Division 1.5 (blasting agent) materials, compatibility group D are transported in the same freight container as Division 1.2 (Class A explosive) materials, compatibility group D, the shipment must be transported as

Division 1.1 (Class A explosive) materials, compatibility group D.

[Amdt. 174–68, 55 FR 52678, Dec. 21, 1990, as amended at 56 FR 66280–66281, Dec. 20, 1991; 57 FR 45464, Oct. 1, 1992; Amdt. 174–68, 57 FR 59310, Dec. 15, 1992; Amdt. 174–75, 58 FR 50237, Sept. 24, 1993; Amdt. 174–83, 61 FR 51339, Oct. 1, 1996]

Subpart D—Handling of Placarded Rail Cars, Transport Vehicles and Freight Containers

§174.82 General requirements for the handling of placarded rail cars, transport vehicles, freight containers, and bulk packages.

- (a) Unless otherwise specified, this subpart does not apply to the handling of rail cars, transport vehicles, freight containers, or bulk packagings, which contain Division 1.6, combustible liquids, Division 6.1 PG III materials, Class 9 materials, or ORM-D materials.
- (b) A placarded rail car, transport vehicle, freight container, or bulk package may not be transported in a passenger train.

[Amdt. 174-68, 55 FR 52680, Dec. 21, 1990, as amended at 56 FR 66281, Dec. 20, 1991; 57 FR 45464, Oct. 1, 1992; Amdt. 174-74, 58 FR 51533, Oct. 1, 1993]

§174.83 Switching placarded rail cars, transport vehicles, freight containers, and bulk packagings.

- (a) In switching operations where the use of hand brakes is necessary—
- (1) It must be determined by trial whether a loaded, placarded car, or a car occupied by a rider in a draft containing a placarded car, has its hand brakes in proper working condition before it is cut off;
- (2) A loaded, placarded tank car or a draft which includes a loaded placarded tank car may not be cut off until the preceding rail car clears the ladder track; and
- (3) A loaded, placarded tank car or a draft which includes a loaded placarded tank car must clear the ladder track before another rail car is allowed to follow.
- (b) Any loaded rail car placarded for a Division 1.1 or Division 1.2 explosive, a Division 2.3 Hazard Zone A gas or a